










## Articulating Hinge



Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
2	1	VM-065-03	HINGE SPACER
3	4	VM-065-00	ARTICULATING HINGE XNMT
4	2	VM-065-1	ARTIC. HINGE ROD
5	4	HD-00163	HairPin Cotter Pin S/S
6	8	HD-00059	3/8 X 1" CARRIAGE BOLT S/S
7	8	HD-00056	3/8 FLANGE HUT BRASS



### To insure you safety while assembling your Voyager product:

- Fully read and understand the assembly instructions
- Do not assemble this product if items are missing or damaged
- Wear protective gloves, clothing and eye wear when assembling this product
- Check tightness of all hardware each year to avoid injury

❖ *Note: You may need assistance when unhooking dock sections and hooking back together*

### Installation procedure

The following tool will be needed: 9/16" wrench, 1/2" wrench

1. Support ends of docks where putting articulating hinge before unhooking.
2. Loosen set bolts on dock connectors with 1/2" wrench and remove. **Per diagram A.**
3. Loosen bolts on add on brackets and remove. **Per diagram B.**
4. Separate docks to allow enough room to install hinges. **Per diagram C.**
5. Insert head of carriage bolts (4) into raceway on the underside of the rail on dock ends. **Per diagram D.**
6. Hook 2 hinge channels to each dock end, keep 1 to each side. Per diagram E.
7. Install 2 carriage bolts and flange nuts to each hinge. Leave nuts loose at this time.
8. Slide docks together and install pins in hinges. **Per diagram E.**
9. Set spacing on hinges **Per diagram F** and the tighten bolts with 9/16" wrench.
10. Install hinge spacer over articulating hinge. **Per diagram G.**

DIAGRAM A




DIAGRAM B





DIAGRAM C




DIAGRAM D

DIAGRAM E




DIAGRAM F





DIAGRAM G




DIAGRAM H